

# ROMP Rose

## What is it?

ROMP Rose is a unique clitoral stimulator with original Pleasure Air Technology, the groundbreaking suction-like sensation using waves of contactless air pressure. ROMP Rose's extraordinary shape is designed to put orgasm front and center, with 6 intensities and 4 pattern modes, all in a high quality, rechargeable, silicone-coated toy at an entry-level price.

### Key Selling Messages

- **Pleasure Air™ Technology** – Game-changing tech for an intense, unforgettable orgasm using suction-like air pressure
- **Sensual Shape** – One kiss from this rose and you'll fall in lust with the sensations
- **Come As You Are** – 6 intensity levels, 4 pattern modes – switch it up and get into your groove
- **More Bang, Less Buck** – With top-of-the-line silicone and a powerful rechargeable motor, you get more than you pay for



## FALL IN LUST

### How to play

1. Hold the power button for 2 secs to turn ROMP Rose on. Find your clit. Show her the world!
2. Apply water-based lube to the stimulation head and to your clit.
3. Position the stimulation head on your clit with light pressure.
4. Briefly press the function button to cycle through 6 intensity levels and 4 patterns... and again... and again... until you r-o-o-o-mp. Hold the power button for 2 secs, and ROMP Rose will switch off.

**Travel lock:** Hold both buttons for 3 secs to activate and deactivate the travel lock. The toy will buzz twice and the LED light will flash twice to indicate that the travel lock has been activated. The LED light will flash twice to indicate that the travel lock has been deactivated. Charging the toy will also deactivate the travel lock

# ROMP *Rose*

## How to sell & demo


1. Point out ROMP Rose's eye-catching, unusual shape, and that it's the first flower-shaped toy with Pleasure Air stimulation – a type of suction-style air massage that teases the clit without direct contact to an incredible orgasm.
2. Hold the power button for 2 secs to turn ROMP Rose on, pointing out where the stimulation head slips over the clit, without direct contact with it. Mention that using water-based lube with the toy is recommended.
3. Start the vibrations by short-pressing the function button. Repeat this to cycle through 6 intensity levels and 4 patterns. Invite viewers to feel the different settings with their finger, noting that the toy runs quietly.
4. Hold both buttons for 3 secs to activate and deactivate the travel lock. The toy will buzz twice and the LED light will flash twice to indicate that the travel lock has been activated. The LED light will flash twice to indicate that the travel lock has been deactivated. Charging the toy will also deactivate the travel lock.

## Product features


- Pleasure Air Technology
- 6 intensity levels & 4 vibrating patterns
- Body-safe silicone
- USB cable with magnetic charging pins
- Waterproof (IPX7)
- Travel lock

## MSRP

EUR	USD	CAD	GBP	CHF	NOK	DKK	SEK
49,99	49,99	64,95	49,99	59	499	399	499
HKD	CNY	KRW	SGD	JPY	AUD	NTD	
390	428	65000	75	6700	79	1600	



## Packaging contains



## Technical Information

<b>Model No.</b>	ROS10A
<b>Name</b>	ROMP Rose
<b>Dimensions</b>	L 76.2 mm Circumference: 177.8 mm
<b>Product weight</b>	117 g
<b>Battery capacity</b>	Contains rechargeable li-ion battery (3.7 V, 240 mAh)
<b>Unit dimensions</b>	94x80x62mm
<b>Unit weight</b>	187 g
<b>Warranty</b>	2 years

<b>COLOR</b>	<b>SKU</b>	<b>EAN</b>
PINK	RP301SG4	4251460612586